

# Laminated 8213 Restrictor

## Fitting Instructions



The Maco Laminated 8213 Restrictor has been designed to comply with the planned alterations to BS8213, the requirements are that where deemed necessary (i.e., bedrooms with small children/babies) a restrictor must be fitted that is released by a coordinated two handed operation. No keys or tools should be required to release the restrictor.

Please follow these guidelines for the correct installation of the Maco laminated 8213 restrictor.

It is important that in order for the 8213 restrictor to function correctly that it is fitted onto the sash.

- Locate and fix the restrictor onto the sash.  
It is normal to fit the restrictor in the same position as the friction stay hinges.
- Position and fix the frame stud onto the outer frame, so that when the window is closed the centre of the release mechanism on the restrictor arm is central with the stud.
- Please note that all screw fixings must be stainless steel.

