

Autolatch Restrictor Operating Instructions



Your windows have been fitted with a Maco Autolatch restricting device. It is important that you read these instructions and familiarize yourself with the operation of the Autolatch.

When you open your window the Autolatch restrictor is automatically engaged and restricts how far the window will open. To releases the restrictor please follow the procedure listed bellow.

- Pull the window part way towards the closed position about 20 mm movement of the sash.
- Move the arm of the Autolatch restrictor away from the stud fitted onto the frame.
- Push the window fully open whilst holding the Autolatch restrictor until the arm clears the frame stud.
- When you close your window the Autolatch restrictor automatically re-engages onto the frame stud ready for next time the window is opened.

